


User Manual



Rear view camera

Connect the camera



Maintenance

- * Although this Rear View Camera requires little care, you can still maintain its condition and performance by following these steps:
- * Occasionally clean the camera lens with damp soft cloth.
- * Should you experience any problem with the camera please refer to the troubleshooting guide below prior to returning your camera for repair.
- * Note: The user should not attempt to service the unit beyond that described in the operating instructions. All other servicing should be referred to qualified personnel.

Specifications

Sensor:	1/3 ARO130
Resolution:	1280(H) x 960(V)
Resolution	130W
Lens:	2.8mm
Lens Angle:	120°
IR led:	12pcs
Video Output :	1.0 Vp-p/75 Ohm
Waterproof:	IP69K
Min illumination:	0.1 Lux (day), 0 Lux (with IR)
SNR:	>48dB
Power voltage:	12V
Operation Temp.:	-20°C~+70°C

Accessories

Screw package Manual